

# Hejny Rentals, Inc.

Contractor, Lawn & Garden, and Party Equipment Rentals  
1829 White Bear Ave. - Maplewood, MN 55109  
Phone: 651-770-3841 – Fax: 651-770-1725  
[www.hejnyrental.com](http://www.hejnyrental.com)

## SAFETY

To prevent personal injury or property damage, read and follow all instructions and warnings.

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- Do not use appliance for other than intended use.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not operate when the appliance is not working properly or when it has been damaged in any manner. For service information see warranty page.
- The use of accessory attachments not recommended by Focus Products Group International may result in fire, electric shock or injury to persons.
- Do not attempt to repair this appliance yourself.
- Do not use this appliance on the stovetop, under a broiler, in the oven, or in the refrigerator or freezer.
- Do not touch hot surfaces. Use handles and knobs where provided. Use hot pads or oven mitts when handling hot surfaces.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Make sure cover, basket and stem are properly assembled before the appliance is plugged in (see "Instructions for Making Coffee" section). No part of the appliance should be removed during the brewing cycle as scalding could occur.
- Scalding may occur if the lid is removed during the brewing cycle.
- To protect against fire, electric shock and injury to persons do not immerse cord, plugs, or other electric parts in water or other liquids.
- Do not operate any appliance with a damaged cord or plug.
- Do not use this appliance outdoors.
- Be sure switch is turned to "OFF" before plugging the cord into wall outlet. If the appliance does not have a switch, be sure the appliance contains water or brewed coffee before plugging in. Do not leave appliance plugged in when it is not being used.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
- Always unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning.
- A short power-supply cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
- Longer extension cords are available, but care must be exercised in their use. While use of an extension cord is not recommended, if you must use one, ensure that the marked electrical rating of the extension cord is equal to or greater than that of the appliance. If the plug is of the grounded type, the extension cord must be a grounding- type 3-wire cord. To avoid pulling, tripping or entanglement, position the extension cord so that it does not hang over the edge of the counter, table or other area where it can be pulled on by children or tripped over.
- Do not use an outlet or extension cord if the plug fits loosely or if the outlet or extension cord feels hot.
- Keep cord away from hot parts of the appliance and hot surfaces during operation.
- Close supervision is necessary when this appliance is used by or near children.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

## Need It. Rent It!

**INSTRUCTIONS FOR MAKING COFFEE**

1. Before using the coffeemaker for the first time, clean it thoroughly. Refer to "Cleaning your Coffeemaker."
2. Always use the coffeemaker on a dry, level, heat-resistant surface, away from any edge.
3. With the basket and stem removed, fill the coffeemaker with COLD water to just above the faucet. Check for any dripping. If dripping occurs between the faucet and the coffeemaker body, tighten the nut inside the coffeemaker. If the dripping occurs from the faucet spout, tighten the faucet bonnet. If there is no dripping present, or has been stopped, fill the coffeemaker with cold water to the desired cup level. Marks on inside of the coffeemaker show cup levels. Do not fill past maximum cup level.
4. Place the stem and basket in the coffeemaker. For models with a plastic basket, you may find it easier to insert the stem in the opening in the basket then squeeze the top of the basket to hold the stem in place. Place the stem into the heating well in the bottom of the coffeemaker. Or, place the stem into the heating unit well, angle the stem away from you, then place the basket on the stem. When they're connected, let the basket and stem tip upright. Add electric perk or regular grind coffee to the basket using the chart below for the amount to use depending on the cup level. Spread the grounds evenly in the basket. Use standard measuring cups to measure the grounds. Do not let any grounds fall into the stem opening. Do not use "Drip" or finely ground coffee because the basket can flood. The amount of ground coffee recommended will make mild- strength coffee which most people prefer. The amount of coffee used can be adjusted to suit your preference.
5. Place the cover on the coffeemaker and turn to lock into the handle slots. Note the arrows on the cover for correct turning. To reduce coffee spills, especially if the coffeemaker is tipped over, make sure that the cover has been turned clockwise until the cover is completely locked into the handle slots. Note: While moving an appliance containing hot liquids is not recommended, if you must move the coffeemaker, extreme caution should be used because the cover only temporarily reduces coffee from spilling if the coffeemaker is tipped over.
6. Plug the cord into a 120 volt AC grounded electric outlet ONLY. If applicable, set the "ON/OFF" switch to "ON."
7. The coffeemaker will stop perking automatically (each cup requires no longer than 1 minute brewing time). Coffee is ready when the light in the base glows. Coffee will remain at serving temperature as long as the coffeemaker is plugged in (and the switch is "ON"). Before serving, turn the cover to remove the basket and stem. Using a hot pad, remove the coffee basket, and stem. If the coffee basket and stem are not removed, bitter oils from the extracted grounds will drip into the coffee. Replace the cover making sure it is completely locked into the handle slots.
8. For cup-on-saucer filling, press the faucet handle down. Release the handle when filled. For continuous flow when filling the coffee server, lift handle straight up until it locks into the open position. Lower the handle when the server is filled.
9. When about 3 cups of coffee remain in the coffeemaker, or when the coffee can no longer be seen in the view tube, turn the switch "OFF" and unplug the cord from the electrical outlet. Note: Liquid must always cover the inside bottom of the appliance at all times. Falling below the minimum level could cause overheating and damage to internal components and will void the warranty.

**SPECIAL NOTE ON GRINDING COFFEE BEANS:** If you grind your own coffee beans, grind to medium coarseness for best results. DO NOT grind too fine (powder-like) because this can cause the basket to flood.

**100-CUP MODEL**

<b>Water Level</b>	<b>Measure of Ground Coffee</b>
100 cups	6 ¼ cups
80 cups	5 cups
60 cups	4 cups
40 cups	2½ cups

Do not make less than 40 or more than 100 cups of coffee at one time.

**55-CUP MODEL**

<b>Water Level</b>	<b>Measure of Ground Coffee</b>
55 cups	3½ cups
45 cups	2¾ cups
35 cups	2 cups
25 cups	1½ cups

Do not make less than 25 cups or more than 55 cups of coffee at one time.

**Need It. Rent It!**

## INSTRUCTIONS FOR HEATING WATER FOR INSTANT BEVERAGES

Plain water may be heated in your coffeemaker for use with instant beverages. Simply fill the clean coffeemaker with cold water to the desired cup level, insert the stem and the clean, empty basket into position the same as for making coffee.

Secure the cover in place and plug the coffeemaker in. If applicable, set the "ON/OFF" switch to "ON." Heat the water until perking stops and the light on the base glows. Remove the cover, lift out the basket and stem with a hot pad, and replace the cover, making sure it is locked in place. Unplug the coffeemaker when less than 3 cups of water remain. The inside of the coffeemaker may darken after heating water, which is normal and does not affect the coffeemaker or the water heated.

Other than making coffee or heating water, no other liquid should be heated in the coffeemaker because damage to the heating unit can occur.

When the coffeemaker is used to heat water only, it must be cleaned well after each use in addition to special weekly cleaning with white distilled vinegar for removal of mineral deposits. If these deposits are not removed, pitting of the metal can occur and result in damage to the coffeemaker. See "Special Cleaning – Every Two Weeks" in this manual. Improper cleaning of the coffeemaker, especially the heating unit well, will affect the performance, resulting in weak, lukewarm coffee and may even cause the coffeemaker to stop perking. To keep the coffeemaker working properly, it is very important to follow the regular and special cleaning instructions.

### HELPFUL HINTS

- Never make less than the minimum or more than the maximum amount of coffee for your coffee urn.
  - Do not use soft water, as flooding of the basket may occur.
  - Use regular electric perk grind coffee or coffee ground for all coffeemakers for best results. Do not use drip or finely ground coffee as flooding of the coffee basket can occur. If grinding your own coffee beans, grind to medium coarseness for best results. Do not grind coffee too finely, powder-like, as this can cause the coffee basket to flood.
  - Remove coffee basket with grounds as soon as the brewing cycle is completed.
- This also helps maintain the coffee flavor. Use the coffee maker cover as a carrying tray when disposing of wet grounds.
- If dripping occurs between the faucet and the coffeemaker body, tighten the nut inside the coffeemaker. If the dripping occurs from the faucet spout, tighten the faucet bonnet. If the faucet continues to drip or is damaged, contact customer service; see information on warranty page.
  - Liquid must always cover the inside bottom of the appliance at all times. Falling below the minimum level could cause overheating and damage to internal components and will void the warranty.
  - A small amount of smoke or odor may occur upon heating due to the release of manufacturing oils – this is normal.
  - Some minor expansion or contraction sounds may occur during heating and cooling – this is normal.
  - Do not allow ground coffee to fall into the stem.
  - If more coffee is immediately desired, partially fill the coffeemaker with cold water to reset the thermostat. Empty the water out of the coffeemaker, then repeat steps 3-9.

### CLEANING YOUR COFFEEMAKER

1. Unplug the coffeemaker and allow it to cool. Drain any coffee out of the coffeemaker.
  2. Wash the basket, stem, and cover in warm, soapy water with a dishcloth or sponge. Rinse and dry. Coffee stains on the metal can be removed with a scouring pad. Plastic parts may be washed in the dishwasher, top rack only. Washing any aluminum parts in the dishwasher may cause them to discolor.
  3. Clean the inside of the coffee maker by filling with warm water about one-third of its capacity. Add dish soap and wash with a sponge or cloth. Scour the heating unit well (where the stem fits) with the special cleaning tool provided and a scouring pad. Twist the pad inside the heating unit well to clean. The heating unit well must be kept clean for coffeemaker to work properly. Rinse with warm water after cleaning and dry.
  4. Clean the outside of the coffeemaker with a damp cloth and dry with a soft cloth.
- Do not use abrasive metal scouring pads or cleansers on the outside of the coffeemaker because scratching will occur.

Need It. Rent It!