Hejny Rentals, Inc.
Contractor, Lawn & Garden, and Party Equipment Rentals
1829 White Bear Ave. - Maplewood, MN 55109
Phone: 651-770-3841 – Fax: 651-770-1725
www.hejnyrental.com

KEROSENE HEATER

DANGER! CARBON MONOXIDE POISONING MAY LEAD TO DEATH! EARLY SIGNS OF CARBON MONOXIDE POISONING RESEMBLE THE FLU, WITH HEADACHES, DIZZINESS, AND/OR NAUSEA. IF YOU HAVE THESE SIGNS, THE HEATER MAY NOT BE WORKING PROPERLY. GET FRESH AIR AT ONCE!!

USE ONLY KEROSENE! NEVER USE GASOLINE, NAPHTHA, ALCOHOL, OR OTHER HIGHLY FLAMMABLE FUELS.

ALL FLAME, INCLUDING THE PILOT LIGHT, IF ANY, SHALL BE EXTINGUISHED AND THE HEATER ALLOWED TO COOL, PRIOR TO FUELING.

USE ONLY IN WELL-VENTED AREAS. BEFORE USING HEATER, PROVIDE AT LEAST A 3 SQUARE FOOT OPENING OF FRESH OUTSIDE AIR FOR EACH 100,000 BTU/HR OF RATING. ALLOW FOR 4 CUBIC FEET OF CLEARANCE AROUND HEATER AND PLACE HEATER AT LEAST 8 FEET AWAY FROM OUTLET.

LOCATE HEATER ON A STABLE AND LEVEL SURFACE.

UNPLUG HEATER WHEN NOT IN USE.

NEVER USE HEATER IN LIVING OR SLEEPING AREAS!

NEVER MOVE, HANDLE, REFUEL, OR SERVICE A HOT, OPERATING, OR PLUGGED-IN HEATER.

TO START HEATER:

1. FOLLOW ALL VENTILATION AND SAFETY INFORMATION.
2. FUEL TANK WITH KEROSENE.
3. ATTACH FUEL CAP.
4. PLUG POWER CORD OF HEATER INTO THREE-PRONG, GROUNDED EXTENSION CORD. EXTENSION CORD MUST BE AT LEAST 6' LONG.
5. PLUG EXTENSION CORD INTO STANDARD 120 VOLT/60 HERTZ, THREE-HOLE, GROUNDED OUTLET. HEATER WILL START WHEN EXTENSION CORD IS PLUGGED INTO OUTLET. IF NOT, PUSH IN FLAME-OUT CONTROL RESET BUTTON.