MEYER/INTEC INSULATION VACUUM LOAD/UNLOAD CHECKLIST

	OUT / IN
HOSES	
6" 20' DISCHARGE HOSE	
4" 50' INTAKE HOSE	
4" 50' INTAKE HOSE	
DOES CUSTOMER NEED EXTRA 50' INTAKE HOSE?	
WAND	
GAS TANK	
CLAMP BOX (8 STRAPS, 2 ADAPTERS)	
DISPOSABLE BAGS FOR SALE?	
CUSTOMER SIGNATURE	
DATE	

Hejny Rentals, Inc.

Contractor, Lawn & Garden, and Party Equipment Rentals 1829 White Bear Ave. - Maplewood, MN 55109

Phone: 651-770-3841 – Fax: 651-770-1725 www.heinvrental.com

Meyer Versa-Vac 15 Insulation Vacuum

GENERAL SAFETY

Safety is proudly built into every product manufactured by Wm. W. Meyer and Sons, Inc. Carelessness and / or negligence are the usual causes for personnel injury and equipment failure. Safety is very important to everyone so we insist that all operators read and understand this manual. Equipment is to be operated by trained qualified personnel only.

Always read and follow the operating and safety procedures.

Do not operate without all guards and safety equipment installed in the proper location and in working order.

Do not disable any safety features. They are there for your protection.

Always use qualified personnel when repairing or maintaining the equipment.

This equipment must be used only for the purpose for which it was intended. Any other use will void the warranty and could cause bodily injury to the operator and costly damage to the equipment.

If a malfunction should occur, turn the machine off immediately and correct the problem, before restarting the machine.

Do not leave the equipment unattended while it is running.

Do not wear loose clothing or jewelry when operating this equipment. Long hair should be confined by a hat or a hair net.

Do not operate under the influence of alcohol or drugs.

VACUUM SAFETY

Limit the operation only to those personnel trained in the proper use and operation of the machinery.

Never operate the machine without proper ventilation.

Keep all clothing and your body away from the rotating equipment.

Obey all safety labels and instructions affixed to the machine

Never run the machine speed faster than the factory settings.

If there are any questions as to the safe operation of this equipment, please do not hesitate to contact us at 1-800-797-8227

SPECIFICATIONS

PURPOSE

The Meyer VERSA-VAC is designed to safely and easily remove insulation.

START-UP

AT ALL TIMES KEEP YOUR HANDS, CLOTHING, ETC. AWAY FROM THE INLET AND DISCHARGE OF YOUR VERSA-VAC.

Place your **VERSA-VAC** on a level surface. Position it so the filter bag will not be blown by the wind and come in contact with the exhaust system. Apply the brake located on the swivel caster.

Attach the filter bag to the **VERSA-VAC** discharge using the strap clamp provided.

Attach the hose to the inlet of the VERSA-VAC using the clamp provided.

Additional hose lengths may then be attached to the hose using hose connectors and clamps.

DO NOT OVERFILL THE GAS TANK. ALLOW ROOM FOR EXPANSION OF THE FUEL. DO NOT LET THE FUEL LINE COME IN CONTACT WITH THE EXHAUST SYSTEM.

Refer to the engine manual for the correct starting procedures for the engine. Start the engine.

Your VERSA-VAC is now ready for service.

REMEMBER SAFETY FIRST!!!!!!

When not using the VERSA-VAC move the throttle to the slow position.

Your VERSA-VAC is a powerful vacuum and should be treated as such. Wooden boards, nails and other foreign materials other than dust are commonly found in duct systems. There is always the possibility of these objects penetrating the filter bag. Keep children and pets away from the machine while it is running.

SHUT DOWN

Move the throttle to the slow position. Run the machine for approx. 5 minutes.

Turn the engine off

Remove the bag.

Disconnect the hose

CAUTION! Do not remove the hose or the bag until the VERSA-VAC has come to a complete stop!

Need It. Rent It!