

Hejny Rentals, Inc.

Contractor, Lawn & Garden, and Party Equipment Rentals
1829 White Bear Ave. - Maplewood, MN 55109
Phone: 651-770-3841 – Fax: 651-770-1725
www.hejnyrental.com

Steamex Triumph 430

Safety

Warning! Read all instructions before using this machine!

Warning! To reduce the risk of fire, electric shock, or injury:

1. You must have training in the operation of this machine before using it.
2. Machines can cause an explosion when near flammable materials and vapors. Do not use this machine with or near fuels.
3. Do not use this unit for dry pick-up of dust or dry debris.
4. To prevent electric shock, always remove the electrical plug from the electrical outlet before doing any repairs .
5. To prevent injury, always remove the electrical plug from the electrical outlet before leaving the machine.
6. Maintenance and repairs must be done by authorized personnel only.
7. Do not immerse. To reduce the risk of electrical shock, use only on carpet moistened by the cleaning process. Protect the machine from rain. Keep the machine in a dry building. Always clean the machine with a clean dry cloth.
8. Always use a three-wire electrical system connected to the electrical ground. For maximum protection against electrical shock, use a circuit that is protected by a ground fault circuit interrupter.
9. Make sure all switches are turned off before plugging or unplugging the power cord into/from a wall receptacle.
10. Do not use water that is hotter than 140 degrees F.
11. To prevent damage to the solution system components do not store in freezing temperatures without proper maintenance.
12. Do not use with damaged cord or plug.
13. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
14. Do not handle plug or appliance with wet hands.
15. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
16. Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

Operating

1. The area to be cleaned should be vacuumed thoroughly to remove loose debris.
2. Fill the fresh water tank with 3-1/2 to 4 gallons of water including carpet extraction chemical. Powdered chemical must be premixed with water before pouring into solution tank.
3. If an extension cord must be used, use only a 14 gauge or larger cord.
4. After the machine is filled with solution, connect the power cord plug into a 115 volt grounded wall socket.
5. Lower the floating brush chassis using the lift bracket in front of the Dome assembly. Lift the handle off the lift stop bracket and lower until the brush contacts the floor. (Always raise and lock the brush chassis for transport and storage).
6. For routine carpet extraction as a self-contained unit, turn the spot valve on the back of the machine to the "Automatic" position. Turn the valve toward "Accessory" only when using a wand, tool, or for storage.
7. The "Vacuum" switch is mounted in the switch panel on the handle assembly. The "Accessory Pump" switch is located in front of the switch panel on the right hand side. The green/white/red "Pump/Brush" switch is located at the rear/center of the handle. Turn on the vacuum switch to start the vacuum motor. Note: DO NOT turn the accessory pump switch on unless the spool valve is turned to the "Accessory" position.
8. Your machine is designed to be pulled backward during operation. (DO NOT attempt to operate in a forward direction). Position yourself behind the machine, grasp the handle and depress the green/white/red momentary switch. This switch activates the brush drive motor and the pump. Walk slowly backward to perform the cleaning process.
9. Release the green/white/red momentary switch approximately 6" before completing each pass. The spray jets are located behind the vacuum head making it necessary to pull the machine a few inches further to pick up the last amount of solution dispensed onto the carpet.
10. Tilt the machine back on the rear wheels and walk forward to position the machine along side the previous pass slightly overlapping.
11. A filter is located inside the solution tank opening. This filter should be checked periodically for build-up of debris. Clean as necessary.
12. As dirty solution is recovered, some foaming may be noted. Excessive foaming can be counteracted with liquid defoamer applied according to the chemical manufacturing recommendations. (Note: Marvel All-In-One Extraction Carpet Cleaner contains defoamer). Do not allow foam to rise into or near the dome. Used defoamer or empty and flush the recovery tank.
13. To empty the recovery tank, remove the dome assembly and lift out the recovery tank.
14. If streaking occurs after a period of operating time, this means the solution or fresh water is near empty. Streaking will be eliminated with addition of more water and chemical solution to the tank.
15. The pump motor in this machine is equipped with an automatic thermal protection device. Should the motor overheat for any reason, the thermal protector will activate and automatically turn the motor off. If this occurs the operator should turn the manual pump switch to the off position and allow a period of time (approx. 15 min.) for the motor to cool. When the motor has cooled to a safe operating temperature, the thermal protector will close and allow power to be supplied to the motor via the manual pump switch. The operator may then, resume normal operation. If the pump shuts down repeatedly, it should be checked.

Need It. Rent It!