

# Hejny Rentals, Inc.

Contractor, Lawn & Garden, and Party Equipment Rentals  
1829 White Bear Ave. - Maplewood, MN 55109  
Phone: 651-770-3841 – Fax: 651-770-1725  
[www.hejnyrental.com](http://www.hejnyrental.com)

## Triumph 1190 Carpet Cleaner Extractor

### **WARNING: To reduce the risk of fire, electric shock, or injury:**

1. You must have training in the operation of this machine before using it.
2. Machines can cause an explosion when near flammable materials and vapors. Do not use this machine with or near fuels, grain dust, solvents, thinners, or other flammable materials.
3. Do not operate this machine unless it is completely assembled.
4. Do not use this unit for dry pick-up of dust or debris; Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
5. To prevent electric shock, always remove the electrical plug from the electrical outlet before doing any repairs or maintenance to this machine.
6. To prevent injury, always remove the electrical plug from the electrical outlet before leaving the machine.
7. Maintenance and repairs must be done by authorized personnel only.
8. Do not immerse. To reduce the risk of electrical shock, use only on carpet moistened by the cleaning process. Protect the machine from rain. Keep the machine in a dry building. Always clean the machine with a clean dry cloth.
9. Always use a three-wire electrical system connected to the electrical ground. For maximum protection against electrical shock, use a circuit that is protected by a ground fault circuit interrupter. Consult your electrical contractor.
10. To prevent damage to the power cord, do not move this machine over the power cord. Always lift the power cord over the machine. Do not pull or carry cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
11. Make sure all switches are turned off before plugging or unplugging it power cord into/from a wall receptacle.
12. Do not use water that is hotter than 60°C (140°F).
13. To prevent damage to the solution system components do not store in freezing temperatures without proper maintenance.
14. Do not allow to be used as a toy. Close attention is necessary when used near children.
15. Do not use with damaged cord or plug. If the machine is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
16. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
17. Do not handle the plug or machine with wet hands.
18. Do not put any object into openings. Do not use with any opening blocked. Keep free of dust, lint, hair and anything that may reduce the airflow.
19. Keep hair, loose clothing, fingers and all parts of body away from openings and moving parts.
20. Use extra care when cleaning on stairs

### **Operating Procedures**

The SELF CONTAINED EXTRACTOR is the most “user friendly” self-contained extractors available. The following procedures are intended to describe and detail proper operation of your machine. Failure to follow these recommended procedures can reduce the machine’s performance and may result in damage to the machine.

1. Vacuum the area to be cleaned. Your machine will do a more thorough job if the loose dirt and debris are removed before the extraction process begins.

## Need It. Rent It!

2. Fill the fresh water tank (lower tank) with water and Heavy Duty Carpet Extraction chemical. Hot water is recommended, but not required. Do not use water hotter than 60°C (140°F). Mix in chemicals according to the chemical manufacturer's recommendations.
3. Use of an extension cord is not recommended. However, if one is necessary, use only a 14 gauge or larger cord.  
Smaller or inferior cords are dangerous and may cause damage to your machine.
4. After the machine is filled with solution, connect the power cord plug to a 115 volt grounded wall socket. See Grounding Instructions.
5. Lower the floating brush chassis using the lift handle located in the front of the machine. Lift the handle off the lift stop bracket and lower until the brush contacts the floor. Remember to always raise and lock the brush chassis for storage and transport.
6. Turn the spool valve knob (located on the back of the machine) to the:
  - a) "Machine" (horizontal) position for routine carpet extraction as a self-contained unit, or b) Turn it in the "Tool" (vertical) position when using a wand or tool.
7. The switch panel is located on top of the handle and contains the following:
  - a) Turn the vacuum switch on to start the vacuum motor.
  - b) Accessory only pump switch: Do not turn on the accessory pump switch unless the spool valve knob is turned to the tool position.
8. Pull backward during operation. **DO NOT ATTEMPT TO OPERATE IN A FORWARD DIRECTION.** Position yourself behind the machine, grasp the handle and gently lift up on the actuator bar. Lifting the actuator bar activates the brush drive motor and the pump. Walk slowly backward to perform the cleaning process.
9. Release the actuator bar approximately 6 inches before completing each pass. The spray jets are located behind the vacuum head making it necessary to pull the machine a few inches further to pick up the last amount of solution dispensed onto the carpet.
10. Tilt the machine back on the rear wheels and walk forward to position the machine along side the previous pass (slightly overlapping).
11. As dirty solution is recovered, some foaming may be noted. Excessive foaming can be counteracted with liquid defoamer applied according to the chemical manufacturing directions. Do not allow foam to rise into or near the dome. Use defoamer or empty and flush the recovery tank.
12. To drain the recovery tank, place an empty bucket under the drain valve located on back of the machine. To open the drain valve pull the T-Handle up. Close the drain when the bucket is full or the recovery tank is empty. Dispose of the recovered water properly.
13. If streaking occurs after a period of operating time, this means the solution (fresh water) tank is near empty. Streaking is eliminated by adding more water and chemical solution to the tank.
14. To drain the solution tank, attach the small drain or "pump out" hose to the accessory quick connect on the back of the machine. Turn the spool valve knob to the "tool" position. Place the open end of the hose into a bucket and turn on the accessory pump switch. When empty, turn off the pump switch and remove the hose from the quick connect. Also return the spool valve knob to the "machine" position.
15. After each use clean the dome, intake filter and gasket. Do not reinstall the dome until the next use, this will allow the recovery tank to dry out.
16. Raise the brush for chassis for storage.

Need It. Rent It!