

Hejny Rentals, Inc.

Contractor, Lawn & Garden, and Party Equipment Rentals
1829 White Bear Ave. - Maplewood, MN 55109
Phone: 651-770-3841 – Fax: 651-770-1725
www.hejnyrental.com

TEXTURE HOPPER ONLY

IMPORTANT: IF YOU ARE USING YOUR OWN COMPRESSOR, IT SHOULD DELIVER AT LEAST 7 1/2 CFM.

WHAT THE PATTERN PISTOL/HOPPER WILL APPLY-

IN GENERAL IT WILL APPLY ANY SPRAYABLE MATERIAL THAT WILL FEED THROUGH THE HOPPER BY GRAVITY AND WILL GO THROUGH ONE OF THE ORIFICES.

HOW TO ESTABLISH YOUR PATTERN-

YOU CAN CHANGE THE TEXTURE APPLIED BY THE PATTERN PISTOL BY ADJUSTING THESE FOUR THINGS (1) SIZE OF ORIFICE AND ORIFICE OPENING, (2) TRIGGER SETTING, (3) AMOUNT OF AIR PRESSURE, (4) MIX CONSISTENCY.

THE FIRST TWO CAN BE CONTROLLED RIGHT AT THE GUN; THE THIRD AT THE COMPRESSOR; THE FOURTH IS CONTROLLED BY YOUR MIXING EQUIPMENT AND THE MAN WHO RUNS IT.

SIZE OF THE ORIFICE: THE PATTERN PISTOL/HOPPER HAS A CIRCULAR ORIFICE DISC ATTACHED TO THE GUN. YOU CAN SELECT ANY ONE OF FIVE ORIFICE SIZES: 7/32", 1/4", 5/16", 3/8", AND 7/16". TO CHANGE ORIFICE, PULL THE TRIGGER BACK AT LEAST 1/8"; ROTATE THE DISC TO POSITION THE ORIFICE YOU WANT TO USE; THEN TIGHTEN THE THUMBSCREW FINGER TIGHT; IT IS NOT NECESSARY TO USE PLIERS TO TIGHTEN THE ORIFICE DISC. THE SIZE OF THE ORIFICE YOU USE DEPENDS ON THE SIZE OF THE AGGREGATE IN YOUR MIX. IT IS NOT NECESSARY TO DISCONNECT THE AIR HOSE TO REFILL THE HOPPER; RELEASING THE TRIGGER STOPS THE FLOW OF MATERIAL IMMEDIATELY.

MIX CONSISTENCY.

FOLLOW MANUFACTURERS INSTRUCTIONS WHEN MIXING YOUR MATERIALS.

Need It. Rent It!