

Contractor, Lawn & Garden, and Party Equipment Rentals 1829 White Bear Ave. - Maplewood, MN 55109 Phone: 651-770-3841 – Fax: 651-770-1725 www.hejnyrental.com

WALK BEHIND MOWER

SAFETY

DANGER! FAILURE TO COMPLY WITH THE FOLLOWING INSTRUCTIONS MAY RESULT IN SERIOUS INJURY TO THE OPERATOR OR OTHER PERSONS.

- 1. Never operate mower without the proper guards, plates, safety switches, or other safety protective devices in place and properly connected.
- 2. Do not operate the mower without grass bag, side chute, or plug in place.
- 3. When mowing over rough ground or in tall grass, mower must be set at highest cutting position.
- 4. Never attempt to make a cutting height adjustment while the engine is running.
- 5. Do not operate mower when barefoot or wearing open sandals. Always wear substantial footwear and long pants.
- 6. Thoroughly inspect the area where the mower is to be used and remove all debris.
- 7. Do not allow children in yard when mower is operated.
- 8. Do not put hands or feet near or under rotating parts.
- 9. Stop blade and engine whenever you leave operating position behind the handle for any reason, including clearing grass, emptying grass bag, and making any adjustments, repairs, or inspections.
- 10. Before cleaning, repairing, or inspecting, make certain blade and all moving parts have stopped.
- 11. Mow across slopes, never up and down.
- 12. Fill fuel tank with unleaded fuel after the engine has cooled.
- 13. Clean before returning.