

Hejny Rentals, Inc.

Contractor, Lawn & Garden, and Party Equipment Rentals
1829 White Bear Ave. - Maplewood, MN 55109
Phone: 651-770-3841 – Fax: 651-770-1725
www.hejnyrental.com

Husqvarna Brush Saw

Warning! It is important that you read, fully understand and observe the following safety precautions and warnings.

Warning! Because a clearing saw is a high-speed fast-cutting power tool, special safety precautions must be observed to reduce the risk of personal injury.

Warning! The use of any clearing saw may be hazardous. If the rotating cutting tool comes in contact with your body, it will cut you. When it comes in contact with solid foreign objects such as rocks or bits of metal, it may fling them directly or by ricochet in the direction of bystanders or the operator. Striking such objects could damage the cutting attachment. Thrown objects or damaged cutting tools may result in serious or fatal injury to the operator or bystanders.

WARNING! When the engine is started with the choke in either the choke or start throttle positions the cutting attachment will start to rotate immediately.

Safety

- Observe your surroundings and make sure that there is no risk of people or animals coming into contact with the cutting equipment. The machine operator must ensure that no people or animals come closer than 15 meters while working.
- Never use the machine if you are tired, if you have drunk alcohol, or if you are taking medication that could affect your vision, your judgment, or your co-ordination.
- Wear personal protective equipment.

Warning! Sometimes branches or grass get caught between the guard and cutting attachment. Always stop the engine before cleaning.

Warning! Avoid cutting with the area of the blade between the 12 o'clock and 3 o'clock positions. Because of the speed of rotation of the blade, kickback can occur if you attempt to cut thick stems with this area of the blade.

Warning! Watch out for thrown objects. Always wear eye protection. Never lean over the cutting attachment guard. Stones, rubbish, etc. can be thrown up into the eyes causing blindness or serious injury.

Adjusting the Harness

Safety release - At the front is an easily accessible, quick release. Use this if the engine catches fire or in any other emergency situation that requires you to free yourself from the machine and harness.

Spreading the load onto your shoulders - A well-adjusted harness and machine makes work much easier. Adjust the harness for the best working position. Tension the side straps so that the weight is evenly distributed across both shoulders.

Correct height - Adjust the shoulder strap so that the cutting attachment is parallel to the ground.

Correct balance - Let the cutting attachment rest lightly on the ground. If you use a saw blade it should balance about 10 cm above the ground to prevent contact with stones and the like. Adjust the position of the support hook to balance the clearing saw correctly.

Warning! When using a clearing saw it must always be hooked securely to the harness. Otherwise you will be unable to control the clearing saw safely and this can result in injury to yourself or others. Never use the harness with a defective quick release. Always use a double harness that distributes the load across both shoulders.

Starting

Hold the body of the machine on the ground using your left hand (Caution! Not with your foot!). Grip the starter handle, slowly pull out the cord with your right hand until you feel some resistance (the starter pawls grip), now quickly and powerfully pull the cord. Never twist the starter cord around your hand. Reset the choke control as soon as the engine fires and repeat until the engine starts. When the engine starts quickly apply full throttle; the throttle will automatically disengage from the start setting. Caution! Do not pull the starter cord all the way out and do not let go of the starter handle when the cord is fully extended. This can damage the machine.

Cold Engine

Ignition: Set the stop switch to the start position.

Choke: Set the choke control in the choke position. This should automatically set the stop switch to the start position.

Air Purge: Press the air purge diaphragm repeatedly until fuel begins to fill the diaphragm. the diaphragm need not be completely filled.

Warm Engine

Ignition: Set the stop switch to the start position.

Choke: Set the throttle to the start position by moving the choke control to choke position and then returning it to its original position.

Air Purge: Press the air purge diaphragm repeatedly until fuel begins to fill the diaphragm. The diaphragm need not be completely filled.

Need It. Rent It!

For throttle handles with a start throttle lock: Set the throttle to the start position by first pressing the throttle lock and the throttle trigger, then pressing the start throttle button. Then release the throttle lock and the throttle trigger, followed by the start throttle button. The throttle function is now activated. To return the engine to idle, press the throttle lock and the throttle trigger again.

Stopping

Stop the engine by switching off the ignition.

Need It. Rent It!