

HEJNY *Rental*

Contractor, Lawn & Garden, and Party Equipment Rentals

1829 White Bear Ave. - Maplewood, MN 55109

Phone: 651-770-3841 – Fax: 651-770-1725

www.hejnyrental.com

Parking Lot Striping Machine

Loading and Operation

- 1) Shake aerosol can vigorously for one minute and occasionally during use.
- 2) Turn can upside-down and place can in can holder. Make sure long side of the spray tip is parallel to axle. Then slide paint can toward center of cart where it will snap into place.
- 3) Adjust line width by loosening wing nuts and raising or lowering the can holder. (Raise to make wider, lower to make narrower).
- 4) Push machine and squeeze hand lever to activate paint spray.
- 5) To remove spray can, slide can toward side of machine and lift out.

Need It. Rent It!